



**SDHQ Motorsports**  
**190 S McQueen Rd**  
**Ste 109 Gilbert, AZ 85233**  
**Phone: 480-633-2929**

---

## Product Packing List

**Product:** SDHQ-52-1131/1132-200

**Description:** **2008-2021 Land Cruiser Switch Pros 9100  
Keypad Mount**

\_\_\_\_\_ (1) SDHQ Laser Cut Land Cruiser Panel

- 2016-2021 Black Panel
- 2016-2018 Flaxen Panel
- 2018-2021 Beige Panel
- 2008-2015 Black Panel

SDHQ-52-1131-200-BL  
SDHQ-52-1131-200-FX  
SDHQ-52-1131-200-BG  
SDHQ-52-1132-200  
SDHQ-52-1131-200

\_\_\_\_\_ (2) 3D Printed Backers

**Inspected and Packaged By:** \_\_\_\_\_ **Date:** \_\_\_\_\_

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929  
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. [www.sdhqoffroad.com](http://www.sdhqoffroad.com)





SDHQ Motorsports  
190 S McQueen Rd  
Ste 109 Gilbert, AZ 85233  
Phone: 480-633-2929

## INSTALLATION INSTRUCTIONS

**Product:** SDHQ-52-1131/1132-200

**Description:** 2008-2021 Land Cruiser Switch Pros 9100  
Keypad Mount



<u>Parts List</u>	<u>Hardware List</u>	<u>Required Tools</u>
(1) SDHQ Laser Cut Land Cruiser Panel SDHQ-52-1131-200-BL SDHQ-52-1131-200-FX SDHQ-52-1131-200-BG SDHQ-52-1132-200	(2) 3D Printed Backers SDHQ-52-1131-200	Flathead Screwdriver 8mm Socket 10mm Socket Thread Locker (recommended) Plastic Panel Remover
<u>Tech Notes</u>		
Utilizes Switch Pros hardware for mounting. **Approx. Install Time = 1 Hour (not including wiring)**		

\*\*\*READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION!\*\*\*


For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929  
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. [www.sdhqoffroad.com](http://www.sdhqoffroad.com)

## **Installation Instructions:**

1. Unbox all of the parts and familiarize yourself with them.
2. **Prepare your Land Cruiser.** Remove the (2) 8mm bolts underneath the knee airbag. Then, using a plastic panel remover, pry open the cover underneath the gas release lever to access the (1) 10mm bolt and remove it.



3. Now remove the panel below the gas and hood release mechanism and disconnect all connections. Take note of where the (2) rear tabs are located for assembly later.





4. Now pry off the panel underneath the steering column and disconnect any electrical connections and take note of where each connection goes. Start from the bottom and work towards the top and pull out.





5. Now that the Seat Switch Panel is exposed, carefully pull it from the dash. Disconnect all of the OEM switches from their wire harness connectors. Remove the switches from the panel. The switches have clips holding them to the back and will be pushed through the front face of the uncut panel.
6. **Installing your Switch Pros.** Locate the (4) threaded studs supplied with your Switch Pros and apply thread locker to one end. Install the threaded (with thread locker) end of the Switch Pros hardware into the back of the Switch Pros Keypad. Insert the Switch Pros into the SDHQ Laser Cut Panel. Align the Backer as pictured. Thread on the Switch Pros supplied nylock nut and tighten by hand until there is resistance on the nuts and the Backers are flush with the Keypad. **NOTE:** The backers are not side dependent.



7. **Reinstalling the Panels.** Follow steps 2-6 in reverse order to complete install. Be sure to run all necessary wiring before completing the install.
8. **Enjoy your SDHQ mounted Switch Pros!**



**\*\*\*Double check all hardware is installed correctly and tight\*\*\***

**\*\*\*Re-torque ALL bolts after 100 miles\*\*\***



190 S McQueen Rd  
Ste 109 Gilbert, AZ 85233  
Phone: 480-633-2929 | Fax: 480-633-1791  
[www.sdhqoffroad.com](http://www.sdhqoffroad.com)

Follow us on:



Facebook



Instagram

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929  
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. [www.sdhqoffroad.com](http://www.sdhqoffroad.com)