



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

Product Packing List

Product: SDHQ-53-1132/1133-63

Description: 14-21 Tundra Switch Pros Keypad Mount

_____ (1) SDHQ Tundra Shifter Panel Keypad Mount	
○ Platinum Edition Panel	SDHQ-53-1132-63-A
○ 1794 Edition Panel	SDHQ-53-1133-63-A
_____ (1) 1/8" Black Acrylic Spacer	SDHQ-53-1132-63-B
_____ (1) 1/4" Black Acrylic Backer	SDHQ-53-1132-63-C

Inspected and Packaged By: _____ Date: _____

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com

**For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com**



SDHQ Motorsports
 190 S McQueen Rd
 Ste 109 Gilbert, AZ 85233
 Phone: 480-633-2929

INSTALLATION INSTRUCTIONS

Product: SDHQ-53-1132/1133-G3

Description: 14-21 Tundra Switch Pros Keypad Mount



<u>Parts List</u>	<u>Hardware List</u>	<u>Required Tools</u>
<p><u>Platinum Edition:</u> SDHQ-53-1132-G3-A: Platinum Edition laser worked panel</p> <p><u>1794 Edition:</u> SDHQ-53-1133-G3-A: 1794 Edition laser worked panel</p>	<p><u>All Editions:</u> SDHQ-53-1132-B: 1/8" Acrylic Spacer SDHQ-53-1132-C: 1/4" Acrylic Backer Mount</p>	<p>Plastic Panel Remover 8mm socket Thread Locker (Medium)</p>

Tech Notes

Only fit Keypads made after February 2017 with a bezel step measurement of 3.865" x 1.865"

Utilizes Switch Pros hardware to mount the Keypad.

Approx install time = 30 Minutes (not including wiring)


For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
 Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com



***READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! ***


Installation Instructions:

- 1. Installing the Keypad.** Locate the #6 threaded studs supplied with your Switch Pros Keypad. Apply a medium strength thread locker to one end of the studs and thread studs into the back of the Keypad. Place the Keypad into the opening of the SDHQ supplied panel, making sure the leather is seated underneath the Switch Pros Keypad edge. Flip the panel over and place the 1/8" Acrylic Spacer over the threaded studs and then the 1/4" Acrylic Backer. Thread on the Switch Pros supplied lock nuts with the 8mm socket by hand, tighten in a crisscross pattern until fully seated. (Note: The fitment for the Keypad in the panel is a friction fit, this is to ensure there is enough leather for the edge of the Keypad to properly hold down the leather around the cutout. For ease of install start with one narrow side half way into the panel and work the keypad in until the other side pops into place.)




For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com

- 2. Uninstalling the factory shifter panel.** To start, the shifter needs to be placed in neutral. Using a plastic panel remover, begin on the driver front side of the panel and work towards the rear of the panel. It is set in there snug and can be difficult to remove. Be cautious not to break the (6) mounting clips.



- 3.** Once finished and wiring has been ran, install the panel in the reverse order as removed.



Double check all hardware is installed correctly and tight

Re-torque ALL bolts after 100 miles



190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929 | Fax: 480-633-1791
www.sdhqoffroad.com

Follow us on:



Facebook



Instagram

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com