



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

Product Packing List

Product: *SDHQ-56-1206-150*

Description: 2010+ Lexus GX 460 A-Pillar Light Mounts

_____ (1) Driver Side Light Mount
_____ (1) Passenger Side Light Mount

SDHQ-56-1206-150-A
SDHQ-56-1206-150-B

Inspected and Packaged By: _____ **Date:** _____

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com

**For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com**



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

INSTALLATION INSTRUCTIONS

Product: SDHQ-56-1206-150

Description: 2010+ Lexus GX 460 A-Pillar Light Mounts



Parts List	Hardware List	Required Tools
(1) Driver Side Mount SDHQ-56-1206-150-A (1) Passenger Side Mount SDHQ-56-1206-150-B	N/A	12mm Socket/Wrench Masking Tape Loctite Hood Prop Marker

Tech Notes

***Special Notes: Windshield Wipers CANNOT be operated with Hood open.**

Approx. Install Time: 1 Hour (not including wiring)

Use a hood prop and mark the outline of hood hinges to assist in realignment during install.

*****READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! *****

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com

Installation Instructions:

1. Unbox your SDHQ GX 460 A-Pillar Light Mounts, noting which one is the driver side mount and the passenger side mount.
2. Prop open your hood and start on the driver side hood hinge with the (2) 12mm bolts. Remove the front bolt attaching the hood to the hinge. Next loosen but do not remove the rear bolt. Position your driver side bracket over the hood hinge aligning the front mounting hole while the rear of the mount is angled away allowing access to the rear bolt. Insert the front bolt through the bracket and loosely thread back in still allowing the mount to rotate. **** Mark the outline of the hood hinge to assist with alignment during installation. ****



3. Remove the rear bolt and rotate the mount to align with its hole. Insert bolt through the rear hole of the mount and thread into the hood. Tighten down bolts while aligning hinge with paint outline of previous location on the hood. On the passenger side a small clip will need to be removed to access the rear bolt.



4. Repeat Steps 1-3 for the Passenger Side. Enjoy your SDHQ GX 460 A-Pillar Light Mounts!

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com

*****Double check all hardware is installed correctly and tight*****

*****Re-torque ALL bolts after 100 miles*****



190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929 | Fax: 480-633-1791
www.sdhqoffroad.com

Follow us on:



Facebook



Instagram

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com