



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

Product Packing List

Product: SDHQ-70-1132/1133-G3.X

Description: 15-20 GM Silverado/Sierra 1500/2500/3500
Switch Pros 9100 Overhead Console Mount

- | | |
|---|--------------|
| _____ (1) SDHQ Laser Cut GM Factory Panel | |
| ○ 2015-17 1500/2500/3500 | 70-1132-G3.X |
| ○ 2018-19 1500, 2018-20 2500/3500 | 70-1133-G3.X |
| _____ (1) 3D Printed Switch Pros 9100 Bezel | 00-1130-9100 |
| _____ (1) SDHQ Laser Cut ¼" Acrylic Backer | 70-1132-G3-B |

Inspected and Packaged By: _____ **Date:** _____

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com

Panel Option:

2015-2017 1500/2500/3500 Panels:

- **W/o Power Sliding Rear Window, W/o Garage Door Opener**
 - Shale 70-1132-G3.34
 - Grey 70-1132-G3.35
- **W/o Power Sliding Rear Window, W/ Garage Door Opener**
 - Shale 70-1132-G3.31
 - Grey 70-1132-G3.32
- **W/ Power Sliding Rear Window, W/o Garage Door Opener**
 - Shale 70-1132-G3.25
 - Grey 70-1132-G3.26
- **W/ Power Sliding Rear Window, W/ Garage Door Opener**
 - Shale 70-1132-G3.22
 - Grey 70-1132-G3.23

2018-2019 1500, 2018-2020 2500/3500 Panels

- **W/o Garage Door**
 - Shale 70-1133-G3.08
 - Grey 70-1133-G3.07
- **W/ Garage Door**
 - Shale 70-1133-G3.17
 - Grey 70-1133-G3.16

Installation Instructions:

1. Unbox your SDHQ Laser cut OEM Panel, Bezel and Acrylic Backer and familiarize yourself with them. The Switch Pros Keypad installs to the panel with the hardware included in its kit.
2. **Remove Factory Panel.** Start your install by removing the non-lasered panel from the vehicle. Open the sunglasses holder and gently pry down on the front edge of the panel, once released you can now pull the panel out fully. Be careful to not damage the wiring still connected to the panel.
3. Now, disconnect the dome light rocker switch, the center light, the Homelink switches and power slider switch (depending on your year and vehicle equipment) from the OEM panel.
Note: The panel pictured has the dome light rocker switch and center light only.



4. **Wire your Switch Pro 9100 keypad.** At this point, follow the Switch Pros wiring instructions for your vehicle.

5. **Installing Switch Pros 9100 Keypad.** Start by installing the SDHQ 3D printed Bezel onto the Switch Pros keypad, as shown right. Next, thread the Switch Pros supplied studs (with blue thread locker) into the keypad. Install the Keypad on the panel, place the backer on the backside of the panel and thread the Switch Pros supplied nylock nuts. Align the Keypad before tightening the nylock nuts. Be cautious not to over tighten as the Switch Pros housing can strip easily.



6. **Install Assembled Panel into vehicle.** Now that your SDHQ Laser Cut OEM Panel is fully assembled you can now install into the truck. Start by replacing all OEM switches and center light that you removed earlier, then connect your keypad. To reinstall the assembled panel into the vehicle, start by clipping into the edge furthest toward the front of the vehicle and work your way backwards, checking to make sure you are not pinching any wiring along the way.
7. **Enjoy!** You have now completed the install of your SDHQ Built Switch Pros 9100 Keypad Mount!



For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com

*****Double check all hardware is installed correctly and tight*****

*****Re-torque ALL bolts after 100 miles*****



190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929 | Fax: 480-633-1791
www.sdhqoffroad.com

Follow us on:



Facebook



Instagram

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com