



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

Product Packing List

Product: SDHQ-85-1206-G3

Description: 2022+ Nissan Frontier A-Pillar Mounts

- _____ (1) Driver Side Light Mount
- _____ (1) Passenger Side Light Mount
- _____ (1) Hardware Package
- _____ (2) 2" Pieces of Edge Trim

SDHQ-85-1206-G3-A
SDHQ-85-1206-G3-B
SDHQ-85-1206-G3-HP

Inspected and Packaged By: _____ Date: _____

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com

**For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com**



SDHQ Motorsports
190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929

INSTALLATION INSTRUCTIONS

Product: SDHQ-85-1206-G3

Description: 2022+ Nissan Frontier A-Pillar Mounts



<u>Parts List</u>	<u>Hardware List</u>	<u>Required Tools</u>
(1) Driver Side Mount SDHQ-85-1206-G3-A (1) Passenger Side Mount SDHQ-85-1206-G3-B (1) Hardware Package SDHQ-85-1206-G3-HP	(2) 2" Pieces of Edge trim	12mm Socket Ratchet Plastic Trim Tool Masking Tape Loctite Hood Prop Dremel Tool
<u>Tech Notes</u>		
Special Note: Windshield Wipers CANNOT be operated with Hood open. Trimming of the cowl is required for install Approx. Install Time: 1 Hour (not including wiring)		

READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION!

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.-Fri. 8:00am-5:30pm and Sat. 8:00am-3:30pm Arizona Time. www.sdhqoffroad.com

Installation Instructions:

1. Unbox your SDHQ Nissan Frontier A-Pillar Light Mounts, noting which one is the driver side mount and the passenger side mount. Remove the (2) small cowl pieces on each side of the windshield.



2. Prop open your hood and start on the driver side hood hinge with the (2) 12mm nuts, mark the hood and hinge to ensure the hood is still aligned correctly after install. Loosen both nuts enough to be able to slide in the mount underneath.



3. Starting with the front slot, slide the A-pillar in place and position the mount forward so the notch is sitting over the hood, now make note of where the mount sits on the hood and move the mount enough to apply your edge trim to the edge of the hood.

- 4. Now slide the mount up in its slots as much as possible, checking to make sure the mount and hood hinge are parallel, and tighten both nuts. When sliding the A-pillar over the edge trim, it will be tight, we suggest having a helper to hold hood while placing mount in position.



- 5. Repeat Steps 2-4 for the Passenger Side.

- 6. With both A-Pillar Mounts installed, place both of the cowl pieces roughly back where they sat from factory. Mark both cowl pieces where the A-pillar will slide through them and cut down enough for the cowl piece to clear the mount. (Picture shown is for reference only to the rough location of the cut in the cowl piece).



- 7. Reinstall your modified cowl pieces and enjoy your new SDHQ Built A-pillar Light mounts for your Nissan Frontier!

*****Double check all hardware is installed correctly and tight*****

*****Re-torque ALL bolts after 100 miles*****



190 S McQueen Rd
Ste 109 Gilbert, AZ 85233
Phone: 480-633-2929 | Fax: 480-633-1791
www.sdhqoffroad.com

Follow us on:



Facebook



Instagram

For questions or help with the installation, please call SDHQ Offroad @ 480-633-2929
Mon.–Fri. 8:00am–5:30pm and Sat. 8:00am–3:30pm Arizona Time. www.sdhqoffroad.com