



## Vibration Isolator Install

### Install:

The frame sits on the rubber pad. The bolt keeps it in place, and as the nut is only tightened enough to position it. The rubbers absorb the upward bounce, and keep the bolt from rattling.

.. So, don't squish the rubbers on install... it's all about vibration isolation.

Xtra-Heavy-Duty version shown below, shows thick rubber used but the flat-washers on top, but might need to be bigger diameter, depending on size & shape of the system being anchored.. Taller "top-heavy" systems need beefier anchors !

Addition of a rubber mat underneath the whole engine system dampens radiated vibration-noise from passing through the floor..

This combination quiets trailers an metal floors a LOT !



**BullDogPRO** water blasters are another quality product made by...  
call.. **619-448-8111** or E-mail.. [info@ PressureWasher.net](mailto:info@PressureWasher.net)  
service & main offices.. **10821 Airport Drive El Cajon, CA**

