

PUFP-CT
COUNTERTOP BOX
INSTRUCTIONS

Pop-up style outlet can be flush mounted (recessed) into countertop or surface mounted on top of the countertop.

Cutting the hole:

- A) For flush mounted, used supplied template on back of these instructions to measure the hole size, or make a cut 4 7/8" X 4 11/16" and rout down to a depth of 1/8". From inside the routed area, cut another hole 3 13/16" square all the way down through the countertop.
- B) For surface mounted, cut hole 3 13/16" squared. No routing needed.

Mounting the box:

- A) Always use supplied LEW stamped steel box (PUFP-WB.)
- B) Using rigid conduit, make connections through hub knockouts in box.
- C) Box should be tight to the underside of the countertop.

Making wire connections:

- A) Pull wires through the box and affix to proper slots on the termination block that is attached to the actual pop up unit.
- B) Make sure the wires are inserted deeply into the terminal, leaving no part of the wire exposed outside of it.
- C) Wrap the connections with UL approved electrical tape to ensure protection against hazards.

Mounting the cover:

- A) Drop the cover into the countertop opening and use Phillips head screwdriver with supplied mounting screws. Fasten completely so that the cover will close when not in use.
- B) Deploy the PUSH button to open the lid and expose the receptacle. To close the lid, depress the PUSH button while simultaneously closing the lid with your other hand.