



1. Install rug rollers or glides to the bottom of all outside legs.
2. Secure plastic end caps.
3. Assemble frame by inserting cross arms assembly into side rail receiving bracket.