
479AGFB

- 479AGFB PARTS LIST: 2 – Silver Clamps
 - 2 Thumb Screws
 - 4 Threaded Glides

ASSEMBLY INSTRUCTIONS FOR A TWIN/FULL CLAMP STYLE BED FRAME

- 1. Screw threaded glides (C) into each leg turning glide clockwise. Tighten as far as possible.
- 2. Swing out 4 cross rails which are rived to the side rails to a 90° angle.
- 3. Slide one of the clamps provided over a front and back cross rail on one side of the frame. Fit thumbscrews into the clamps, but do not tighten.



- 4. Line up bed frame headboard brackets with the holes in headboard and bolt securely. Do the same with the footboard end.
- 5. After you have bolted the frame to the headboard and footboard, tighten the 2 clamps on the cross rails of the bed frame.
- 6. Loosen the treaded glides until they touch the floor by turning counterclockwise.

