

# Dura-Rubber Application Instructions (Metal)

## Proper Preparation Prevents Poor Performance

### DURA-RUBBER – METAL

Applying Dura-Rubber over metal as a water proofer corrosion protection.

Applying fabric and product per application chart on all the seams penetrations, splits or cracks in the field, wall caps and intersections with walls. you can extend the life of the roof 5 and even 10 years depending on the condition of the field. Just follow the simple directions below.

While you're on the roof the Dura-Rubber works great to protect and mechanical equipment from rust and UV go to the following links (**HVAC Equipment coatings & Swamp Coolers in this chart**)

**SURFACE PREPERATION:** Surfaces must be dry and free of anything that could adversely affect the adhesion to the surface. You should be sure to remove all loose rust, and scaling, peeling, blistering, chipping, cracking, chalking or gravel, dust, dirt, sand, soot, grease, oil, uncured tar, wax, soap film, animal fats or petroleum-based residue, coal tar, chlorine, salts, efflorescence, or any other chemically reactive substance; and the surface to be coated must be completely free of all mold, mildew or any other living organism and COMPLETELY DRY.

High-pressure 2,500 P.S.I. should be used to thoroughly pressure clean all surfaces prior to application when any of the above conditions exist.

Mildew and similar growths need to be killed with 5% chlorine solution household bleach in water, followed by a thorough rinse with clean water. All surfaces must then be allowed to THOROUGHLY DRY before proceeding with application.

High-pressure 2,500 P.S.I. should be used to thoroughly pressure clean all surfaces prior to application when any of the above conditions exist.

Mildew and similar growths need to be killed with 5% chlorine solution household bleach in water, followed by a thorough rinse with clean water. All surfaces must then be allowed to THOROUGHLY DRY before proceeding with application. We recommend doing a adhesion test before final application

Product must be stirred, by hand slowly for 2-5 minutes, not shaken, or aggressively blended prior to use. DO NOT THIN PRODUCT.

Application Rate: Dura-Rubber

Rates of Application are typically:

**20 mils dry** Coverage is about 40-50sf per gallon.

Apply at the rate maximum of 10 mill per coat two minimum of two coats required.

Remember you are not applying paint you are applying a liquid membrane.

\* These mil thickness recommendations are based on proper application and preparation. Deep Drying / Curing times depend on temperature and relative humidity.

Drying Times:

# Dura-Rubber Application Instructions (Metal)

## Drying times are typically:

Prep coat.

Brushed or Rolled Dura Rubber will be ready to have cloth embedded while still wet and a top coat may be applied.

Make sure fabric is totally saturated with rubber and tight to the surface. This would apply to corners seams and patches. this must dry 1-2 hours depending on the size of crack filled, temperature and relative humidity.

## Application Coat

Products needs to "deep" dry between application coats. This means that because Dura-Rubber is water-based, all water must evaporate out of each application coat prior to the next application coat. Otherwise the rubber will develop small bubbles of fluid between the coats. If you have small bubbles appearing on your project, you need to wait longer between your application coats. Time to dry between applications coats is approximately 1-3 hours - depending on temperature and relative humidity.

## "Curing" or "Vulcanization" Times

You will notice the product is dry to the touch with-in a few hours, and will be waterproof in about 8. If However, the rubber is still going through a very important process called "Vulcanization" - this is the process where the rubber becomes one single membrane and can contain water on a continuous basis. if is going to be totally submerged in water it needs to be totally vulcanized. The process of "Vulcanization" can take 7 days. You do not want to expose coating to chemicals until the vulcanization process is complete.

If you have a question about your specific application please does not hesitate contacting us either via the phone, e-mail or our live online support chat. We are here to help!

If you have a question about your specific application please does not hesitate contacting us either via the phone, e-mail or our live online support chat. We are here to help!

## Optimal vs. Acceptable Humidity Levels

Optimal relative humidity (RH) levels for exterior applications tend to be in the 40-50% range or lower. Levels of 70% or greater will "drastically slow drying and curing," but again will not prevent you from applying.

Applying above a RH level of 85% is strongly not recommended. Coating will remain gummy and gel-like until the RH lowers to an acceptable level long enough for it to solidify.

However, because the coating has not been allowed to "level" properly, the texture will remain wavy and otherwise unacceptable.

## Temperatures Work With Humidity, Too

## **Dura-Rubber Application Instructions (Metal)**

One tip is to time your application so that temperatures are on the rise--several hours before the day's peak temperature, which is usually in the late afternoon.

You need to build in a head-start by beginning hours before you think it is time to begin:

Even though the temperature was OK at the time of application, the coating can stop coalescing. This permits moisture to get into the uncured paint film allowing certain ingredients to come to the surface when the moisture evaporates, causing surface staining and possible adhesion problems.