BEADLOCK B SYSTEM



HOW TO MOUNT THE TYRE



1. To mount the tyre all tapered 45 degrees screws must be previously removed.



2. Then, the tyre can be mounted in its usual way. Once the tyre is inflated, with higher pressure than standard, we must tighten the tapered screws until they collide against the wheel. Only after all the screws are screwed in, we can proceed to restore the normal tyre pressure.



3. The screws have a special sealing gasket washer. It is essential to keep these washers pressing the rim flange. Otherwise, the screw would be stuck more than expected in the tire and the inflation pressure would be lost in the case of mounting without a camera.



DO NOT MOUNT OR DISMOUNT THE TYRES
WITH FETTERED SCREWS PLACED







BEADLOCK B SYSTEM



HOW TO DISMOUNT THE TYRE



1. To dismount the tyre, first remove the screws from its lodge. Then dismount the tyre as usual.



2. Before a new tyre mounting, the tightening area of the washers must be cleaned.



3. The washers are reusable. In case of deterioration or damage BRAID can supply new spare parts.



DO NOT MOUNT OR DISMOUNT THE TYRES WITH FETTERED SCREWS PLACED





