



PREMIER COPPER PRODUCTS

PLUMBING PRODUCTS
DECORATIVE LAVATORY DRAINS



D-207PB



STANDARD INSTALLATION



— 1



— 2



— 3



— 4



— 5

1. SEPARATE ALL MOUNTING HARDWARE AS SHOWN.
2. PLACE A BEAD OF SILICONE UNDER THE DRAIN RIM (1). NOTE: BE SURE TO TRIM AWAY EXCESS SILICONE FROM THE TOP OF THE SEAT (1) AFTER DRAIN IS INSTALLED.
3. PUT DRAIN (1) DIRECTLY INTO DRAIN OPENING OF THE SINK.
4. FROM UNDERNEATH THE SINK SLIDE THE RUBBER GASKET(2), METAL RETAINING RING (3) AND THE LOCK NUT (4) ONTO THE THREADED SEAT (1) AND TIGHTEN INTO POSITION.
5. WRAP THE THREADS ON THE TAIL PIPE (5) WITH TEFLON TAPE.
6. INSTALL TAIL PIPE (5) INTO THE BOTTOM SEAT (1).

CARE & CLEANING INSTRUCTIONS

- * DO NOT USE ALKALINE, ACID BASED DETERGENTS, ABRASIVE POLISHES, SCOURING CLEANSERS, S.O.S. PADS OR SCOTCH BRITE PADS WHEN CLEANING YOUR DECORATIVE LAVATORY DRAINS.
- * DO NOT LEAVE CORROSIVE CHEMICALS OR SOLIDS LAYING IN THE BOTTOM OF THE SINK BASIN, SUCH AS COFFEE GROUNDS, VINEGAR, ETC.
- * AFTER NORMAL USE, ALWAYS WIPE THE EXPOSED SURFACE AREA OF YOUR DRAIN WITH A CLEAN SOFT CLOTH. THIS WILL AID IN LIMITING WATER SPOTS.
- * FOR NORMAL CLEANING, JUST WIPE WITH A DAMP CLOTH AND DRY WITH A SOFT CLOTH.
- * IF YOU DESIRE TO USE A CHEMICAL CLEANER WHEN CLEANING, WINDEX OR A MILD DISH WASHING SOAP CAN BE USED.