



# PREMIER COPPER PRODUCTS

PLUMBING PRODUCTS  
DECORATIVE LAVATORY DRAINS



## D-208PB

### STANDARD INSTALLATION



1. SEPARATE ALL MOUNTING HARDWARE AS SHOWN.
  2. PLACE A BEAD OF SILICONE OR PLUMBERS UNDER THE DRAIN RIM #1.
  3. PUT DRAIN #1 DIRECTLY INTO DRAIN OPENING OF THE SINK.
  4. FROM UNDERNEATH THE SINK SLIDE THE RUBBER GASKET(#2) UP. SLIDE PAPER GASKET(#3) INTO PLACE.
  5. THE THREADS OF(#1) THEN TIGHTEN THE LOCK NUT #4.
  6. INSERT THE SEALING WASHER #5 INTO THE RECESS OF NUT #6.
  7. INSTALL TAIL PIPE #7 INTO THE BOTTOM OF SEAT #1 BY TIGHTENING THE #6 NUT.
- NOTE: BE SURE TO TRIM AWAY EXCESS PUTTY OR SILICONE FROM THE TOP OF THE SEAT #1 AFTER DRAIN IS INSTALLED.

### CARE & CLEANING INSTRUCTIONS

\* DO NOT USE ALKALINE, ACID BASED DETERGENTS, ABRASIVE POLISHES, SCOURING CLEANSERS, S.O.S. PADS OR SCOTCH BRITE PADS WHEN CLEANING YOUR DECORATIVE LAVATORY DRAINS.

\* DO NOT LEAVE CORROSIVE CHEMICALS OR SOLIDS LAYING IN THE BOTTOM OF THE SINK BASIN, SUCH AS COFFEE GROUNDS, VINEGAR, ETC.

\* AFTER NORMAL USE, ALWAYS WIPE THE EXPOSED SURFACE AREA OF YOUR DRAIN WITH A CLEAN SOFT CLOTH. THIS WILL AID IN LIMITING WATER SPOTS.

\* FOR NORMAL CLEANING, JUST WIPE WITH A DAMP CLOTH AND DRY WITH A SOFT CLOTH.

\* IF YOU DESIRE TO USE A CHEMICAL CLEANER WHEN CLEANING, WINDEX OR A MILD DISH WASHING SOAP CAN BE USED.