



APPLICATION GUIDE

Everest Trade - Anti-Slip - High Build Industrial Grade PU Resin-Based Floor & Concrete Paint

SURFACE PREPARATION

- **Wash the floor using a degreasing solution. Rinse the floor until it's clean. If the floor is particularly dirty, is very smooth or power floated, then it must be either mechanically abraded or treated with an etching acid. Remove as much concrete dust as possible before application.**
- **To check whether the etching has worked, pour water onto the concrete to see if it absorbs. If the water beads on the surface, you will need to repeat the etching process.**
- **If there are any holes or cracks in the concrete, fill them using a trowel and patch compound. Let it dry before continuing.**
- **Ensure the surface to be painted is cleaned thoroughly and remove as much concrete dust as possible before application, This can be done by brushing to loosen the dust and vacuuming the dust, It's also recommended to pressure wash beforehand if possible.**
- **Make sure the surface is completely dry before the next steps.**

APPLICATION

- If you need to mask off areas this is the time to do so.
- It may be necessary to cut the edges of the walls /pillars and posts/doorways with a hand paint brush first. This will reduce the chance of paint splatter from your floor roller. However, experienced contractors may feel they can skip this process.
- Before application, thoroughly stir the floor paint with a metal mixing paddle drill attachment, This will ensure the anti-slip particles within the product is mixed correctly and not settled at the bottom of the container.
- We recommend this product is applied with a medium pile double armed roller kit with extension pole, this makes application easier and prevents bending of the roller arm. A paint brush can be used on edges and hard to reach areas.
- Apply one coat of Everest Trade Paints Floor Primer and Sealer Paint using a floor roller. Allow at least 8 hours for the Everest Trade Paints Floor Primer and Sealer Paint to fully absorb into the concrete and dry.
- We recommend applying two coats for the best result and performance. Apply two coats of topcoat using a roller. Apply in thin, even coats for the best results, this will minimise drying times and result in a more durable coating.

Make sure the paint is completely touch dry before applying a following coat and leave a minimum of 24 hours after finishing the final coat, before any vehicles or heavy machinery is allowed onto the floor.

STORAGE PRECAUTIONS

Store away from heat and naked flames. Secure lid between uses to prevent paint hardening. Store away from frost.

**For further assistance please contact our technical
department on 0800 043 8220**