

# Mirrored One-Way Privacy: Internal Application

## Application and Cleaning Instructions

### 1. Preparation

- Clean the glass with mild soapy water\* removing any dust, paint specs, grease or other contaminants.
- Complete a second cleaning if necessary and then rinse off with water only
- Thoroughly dry the surface before application
- Apply the film in temperatures between 3°C (35°F) and 30°C (90°F)
- Cut the film to the window size. Allow 20mm of excess material on all edges which can be trimmed later
- Use a spray bottle to apply a covering of water mixed with 2 drops of dish washing detergent
- Place your film on a flat surface. Carefully peel off the backing film. The film is very thin and care must be taken not to crease. Stick some tape on either side of a corner and peel the tape apart to start the process
- Spray the exposed (adhesive) surface of the film with the water/detergent. Lightly spray your hands to stop the film sticking to them



### 2. Application

- Carefully pick up the film and slide into position on your glass. Keep the film smooth. It will continue to move, providing the glass is wet. Reapply water if necessary
- Spray the film surface with application fluid, which will wash any dust that might scratch the surface and will help to avoid scratching the surface with the squeegee



### 3. Remove air bubbles and trim

- Use the plastic squeegee provided\*\* smooth out the film, handling the material with care. Begin from the centre and work outwards in all directions. Ensure that no bubbles are trapped, especially at the edges
- As a last resort, remove any stubborn bubbles by gently popping them with a pin and rubbing
- Wipe away excess water. There may be some water marks left on the film, however this will dry/ evaporate over time
- To trim: Position the blade on the edge of the squeegee. Run the squeegee and the blade around the edges of the frame. Leave a 1-2mm gap around the edges to ensure reliable edge adhesion



### 4. Cleaning and Aftercare

- Do not wash the film for 24 hours after application to allow the adhesive enough time to work
- Clean with a mild soapy solution using a sponge or microfibre cloth. Do not use abrasive cloths or solvent cleaners



\* Do not use window cleaning spray, as it can damage the film!

\*\* Squeegee not included with samples

