

White Perforated: External Application

Application and Cleaning Instructions

1. Preparation

- Clean the glass with mild soapy water* removing any dust, paint specs, grease or other contaminants.
- Complete a second cleaning if necessary and then rinse off with water only
- Thoroughly dry the surface before application
- Apply the film in temperatures between 3°C (35°F) and 30°C (90°F)
- Cut the film to the window size. Allow 20mm of excess material on all edges which can be trimmed later
- Cut away the top 2 inches of the paper liner. Avoid touching the adhesive, especially the edges and corners




2. Application

- Apply dry. Do not apply wet. Carefully pick up the film and begin the application from the top of the window, ensuring the film is correctly aligned on all sides
- Press the upper corners in place using light pressure. Slowly peel away the liner and using the plastic squeegee provided** squeegee down evenly in a sweeping motion from left to right, handling the material with care, and ensuring that no air bubbles are trapped beneath the material



3. Completion and trim

- To trim: Position the blade on the edge of the squeegee. Run the squeegee and the blade around the edges of the frame. Leave a 1-2mm gap around the edges to ensure reliable edge adhesion
- Complete a final squeegee taking particular care with the edges



4. Cleaning and Aftercare

- Do not wash the film for 24 hours after application to allow the adhesive enough time to work
- Clean with a mild soapy solution using a sponge or microfibre cloth. Do not use abrasive cloths or solvent cleaners



* Do not use window cleaning spray, as it can damage the film!

** Squeegee not included with samples

