

## Installation instructions for X-keys Flippy Feet

- 1) Carefully remove the stick-on standard feet from the top side of the case
- 2) Remove the two screws from the bottom outside corners of the case
- 3) Install the two bumper feet with the long screws
- 4) Unscrew the two screws from the top corners of the case
- 5) Being careful to orient the two bale brackets such that the slots point to the outside edges of the case (see picture Step 5 below), snap them into the case and secure them with the long screws
- 6) Stick the two standard feet over the screws on the bale brackets
- 7) Fit the open ends of the bale into the bale brackets

These pictures show the 4x6 being installed. Follow the same procedure for the 10x8 version using the outside corners.

