

Pro-Package C TDD-PPU-PPC

Pro-Package C consists of 4 separate structures. To install the back wall, assemble the tubes, then zipper on its fabric print. Similarly do the same for the towers and arch. After all prints have been installed, connect the 4 structures together.



1. Separately assemble the frames for the back wall, the towers, and the arch. Connect the poles and match the symbols together. Click together so the button nubs protrude through the holes.



2. Keeping the back wall, tower and arch separate, slide on each of their graphic prints like a pillow-case and then zipper at the bottom. If you ordered a tower monitor mount, attach the monitor mount as shown using 4 screws provided. If you ordered an arch mount, attach it to the arch instead.



3. Attach the pegs to the feet plates used by the back wall and arch using the provided bolts. Use the hand tool included to tighten it. One tower foot that has 3 pegs/extensions on it — two of these pegs are used by the tower, and one is used by the left side of the back wall. Attach the feet to the frames.



4. Find the small hidden zippers in the seams shown by the arrows. Carefully open these so that you can get hands into the tower. Bolt the arch to the tower, from the tower interior, through the tower horizontal pole, through the premade button holes in the fabric, into the arch pole ends. Place the right side of the back wall on the 3-peg shared foot with the tower.



5. Bolt 2 brackets vertically onto the back of your VESA compliant monitor. Hook your monitor onto the frame. Max 20 lbs (9 kg) 36". Clamp display lights to your back wall. Completed installation shown. Tables and chairs for illustrative purposes only. Shown with optional side wall and counters.