



INSTALLATION GUIDE

STEP 1: USE A TRIM TOOL TO CAREFULLY OPEN THE BOTTOM OF THE CAP

STEP 2: PUSH OPEN THE LID AND REMOVE IT

STEP 3: ALIGN THE CARBON FIBER SHIFT KNOB TO THE SHIFTER

STEP 4: PUSH THE CARBON FIBER SHIFT KNOB INTO PLACE

