




1: bracket mounting location	2: Secure bracket with Nut and washer	3: Secure bracket with oil catch can
		
4:(9mm Inlet) Secure Oil catch can fitting with Teflon tape	4:(outlet 15mm)Secure Oil catch can fitting with Teflon tape	6: Remove the PCV Hose



Oil Catch Outlet TO Intake Manifold Match the A to A

Oil Catch Inlet TO PCV Valve Match the B to B

Disclaimer

- Recommend setup diagram ONLY,ADD W1 is not responsible for any vehicle damage or personal injury to your vehicle or personal
- Check oil catch can lever every 500-1000 miles. Please dispose of any liquids properly
- Allow vehicle to cool completely prior to attempting installation
- ADD W1 is not responsible for any vehicle damage or personal injury to your vehicle or personal for installation of all ADD W1 products
- You assume any and all responsibility for any damage or injury that may occur while performing this work
- ADD W1 always suggests that a trained professional install all ADD W1 Products
- Only raise vehicle up on jack stands to on a vehicle lift