

Glassboard

Installation Instructions

for Z-clip Hidden Mounting System

Instructions are intended for drywall installation only. For other surfaces, use appropriate mounting hardware to hold brackets securely to wall.

TOOLS NEEDED:

- Level
- Phillips Screwdriver
- Paper towels or microfiber cloth and window cleaner (for clean-up)

INSTRUCTIONS:

NOTE: The RED DASHED LINES are the most important thing to pay attention to for proper installation!

- 1) Using a level, tape this template in desired location on wall. You **MUST** leave at least $\frac{5}{8}$ " from top edge of glass to ceiling to allow for clearance while mounting glassboard.
- 2) Hold the loose bracket (A) precisely within the gray box shown on template. **NOTE: Holes of brackets will not necessarily line up exactly with circles shown on paper template.**
- 3) Screw one of the WallDog Screws (B) into one of the **SMALL HOLES** near the center of the bracket. Screw should go exactly into the **RED DASHED LINE**. Make it snug, not tight, at this time.
- 4) Rotate the bracket around the installed screw and place a WallDog Screw every 12" along bracket making sure to place a screw near each end of the bracket. **Make all screws SNUG, BUT DO NOT OVERTIGHTEN!**
- 5) Repeat with the 2nd bracket.
- 6) Once the brackets are in place, find a friend to help you lift the glassboard up onto the brackets. You'll be able to slide the glassboard somewhat to the left and right for final adjustment.
- 7) Wipe off glass with window cleaner and a paper towel or damp microfiber cloth.
- 8) Stand back and admire!



A)



B)