

Dirt Warrior Accessories - Rear PRO XP



Helpful Hints for Installation

- Put clamps on roll bar first
- Install from inside the cab
- Tilt Bottom part of window in first and then slowly push top into place. This part sometimes requires 2 people and a little muscle.
- Top should fit fairly tight to roll bar.
- Once window is in place, line up cage clamps to the holes in window frame and loosely (finger)tighten.
- Reposition window one more time to assure fitment and then tighten up the clamps



**Thank YOU for your BUSINESS &
Have A DiRtY DAY!!!**