

O-1800-1 Assembly Instructions

- 1) Screw brass 360 degree spray tip into 10-32 I.D. thread.
- 2) Connect flex wand nut to ridged wand fitting and tighten the 7/16" hex nut into 1/4" compression fitting (do not over tighten)
- 3) When using multiple wands the 4' goes on end and tightens to the 7/16" hex nut into 1/4" compression fitting.
- 4) Connect flex wand nipple to sprayhead connector.
- 5) Screw air gun onto 1/4" adaptor nut connected to sprayhead.
- 6) Connect air source to bottom of air gun.
- 7) For operating instructions refer to O-1800-1 instructions included.

NOTE:

If using multiple wands the 4' is threaded to screw in the 360 degree tip plus one 6' wand. The 1/4" compression cap stays on wand just screw 360 degree tip in and connect the flex wand to other end of wand and connect to sprayhead connection.