

Install a door hinge into the space after it is cut apart and it will be the length you need to cover the entire platen.

