

# Pairing Handlebar controls to your Sony MEX-M72BT or DSX-M80

For 1999 to 2013 bikes only

Leave the handlebar module unplugged until Step 4.



**Step 1**  
Bolt it up

**Step 2**  
Plug it into bike

**Step 3**  
Turn your key on and wait for the radio to turn on.

**Step 4**  
Plug this into the harness.  
When the lights flash rapidly red and green, **press and hold** the volume up button on your handlebars.



1. With the key off, mount your radio to the bike.
2. Plug your Fat Head harness into your bikes' factory harness. (Be sure to fully latch the factory locking mechanism)
3. Turn your ignition on, and wait (up to) 2 minutes for your Sony radio to turn on.
4. After your Sony radio turns on, plug in the module in Step 4 in the picture to the right. Now push & hold the "volume up" button on your handlebar controls until the lights on the module start flashing green then let go of the "volume up" button.

Watch the lights...there will be 7 green flashes, then 4 red flashes, then the light will go solid red for 3 seconds and then go out.

5. Test your handlebar controls



**You're done.**



**Reassemble and ride!**

Thank you for your Fat Head Cycles bundle purchase.  
Inside this envelope you will find what you need to have a successful installation.

