

Instructions

1. Spread out riveted head and foot bars to form a 90° angle with long side bars.



2. Insert rollers or glides.



3. Join both halves of head support, and both halves of foot support, according to box spring format, using bolts & nuts assembly system. Use 5/16" x 3/4" bolts.



4. Install centre support from head to toe if included, using 5/16" X 3/4" carriage bolts and nuts to attach it, without tightening.

5. Install box spring on bed frame. Make final width adjustment, and tighten bolts.



6. Install angle protectors at extremities.



7. If installing a headboard, use 1/4" x 2 1/2" screws to attach frame to headboard.