



# DAX EAR PROTECTION MOUNT INSTALLATION INSTRUCTIONS

## STEP 1



MARK AND DRILL HOLES ON BOTH SIDES  
OF THE HARD HAT

## STEP 2



SCREW THE MOUNTS ON AND TIGHTEN

## STEP 3



ENSURE SCREWS ARE FIRMLY ATTACHED

## STEP 4



REMOVE PREVIOUS BRACKETS, MOUNT  
LEFT AND RIGHT DAX BRACKETS

## STEP 5



ATTATCH LEFT AND RIGHT EARMUFFS TO  
THEIR RESPECTIVE BRACKETS

## STEP 6



RE-INSTALL THE LINER  
AND THE INSTALLATION IS COMPLETE