

Color Matrix		
2	White	
5	Black	
10	Cedar Brown	
30	River Bottom	
34	Timber Brown	
37	Redwood Brown	

Artist's Notebook

You can try using painter's tape if you wish to achieve straight lines between the colors of the speculum.

Painting Instructions

- 1. Prep the entire decoy in accordance with the decoy painting instructions, prime with gray Parker Decoy Primer. Draw lines using a pencil.
- 2. Paint the head, chest, sides, and rump with River Bottom (30).
- 3. Paint the back and tail with Timber Brown (34).
- 4. Use dry brush technique to apply Timber Brown (34) to top of head.
- 5. Paint bill with Cedar Brown (10) and once dry, apply Black (5) dots.
- 6. Paint speculum back to front: White (2), Black (5), and Redwood Brown (37).