

CONTENTS



MB0056-JK

Qty: 1

INSTALLATION

Follow these simple steps to ensure a smooth and bubble-free installation of your new window banner using the wet method.

What You'll Need:

Soapy water in a spray bottle or glass cleaner
Squeegee with felt edge or credit card and a thin soft towel
Lint-free cloth or paper towel
Rubbing alcohol and a clean cloth (for cleaning the window)

Step 1: Clean the Window

Clean your window thoroughly with rubbing alcohol and a lint-free cloth to remove any dirt, grease, or residue. Ensure the window is dry before proceeding.

Step 2: Prepare Soapy Water Solution

Add a few drops of liquid dish soap to a spray bottle, then fill the bottle with water and shake. This solution will help you adjust the position of the banner during installation. Glass cleaner would also be a suitable substitute.

Step 3: Wet the Window

Spray the soapy water generously on the window where the decal will be applied. Don't be shy—more water makes it easier to adjust the banner.

Step 4: Remove the Backing

Carefully peel the backing off the banner, making sure not to touch the adhesive side.

Step 5: Apply the Decal

Spray the adhesive side of the banner and place the banner on the wet window. The soapy water will allow you to slide it into the perfect position.

Step 6: Squeegee Out the Water

Once the banner is in place, use a squeegee with a felt edge or the edge of a credit card wrapped with a thin soft cloth to gently push out the water and air bubbles from beneath the decal. Start from the center and work your way to the edges.

Step 7: Dry

Use a lint-free cloth or paper towel to gently dab around the edges of the banner to remove any excess water.

Step 8: Cure Time

Allow the banner to dry and adhere properly to the window. Avoid driving at high speeds or washing your vehicle for at least 8 hours.

Enjoy your newly installed windshield banner!