

MB3043 - REAR HALF DOORS

COMPATIBLE WITH JEEP JL/JLU & JT GLADIATOR



ASSEMBLY INSTRUCTIONS





Preparation and Installation Guide for Your Jeep JL/JT Rear Doors

Our new front doors is crafted from high-quality aluminum and shipped in bare metal. To achieve the best possible finish and ensure a flawless fit, we recommend the following procedure:


- 1. **Initial Fitting**: Before painting, assemble all components to ensure they fit perfectly on your Jeep JL/JT Rear Doors. This step is crucial to avoid adjustments post-painting that could damage the finish.
- 2. **Disassembly and Cleaning**: Once you confirm the fit, disassemble and thoroughly clean all parts to prepare them for painting.
- 3. **Professional Painting**: For a superior and durable finish, we advise having the door parts professionally prepared and painted by a reputable auto body shop. This ensures the paint is perfectly matched and applied evenly.
- 4. **Final Assembly**: After painting, reassemble the parts for the final installation. This process ensures all components align correctly and maintain their pristine condition.


Additional Recommendations:


By following these steps, you can enhance the aesthetics and functionality of your Jeep JL/JT Rear Doors with confidence that the finish and fit are of the highest quality.


To further protect your investment, consider adding a non-slip marine grade flooring material to the removable interior panel.














BAG LABELED AS MB3043-KIT01





MB3064-JLT Hinge, Upper Driver Qty 1

MB3064-JLT_MIR
Hinge, Upper Passenger
Qty 1





Qty 8



MB3064-JLB

Qty 1

Hinge, Lower Driver

MB3064-JLB_MIR
Hinge, Lower Passenger
Qty 1

Flat Washer, Stainless 5/16" Qty 16




Nylock Nut, Zinc 5/16" UNC Qty 8




CONTENTS

BAG LABELED AS MB3043-KIT02







Rubber Bumper Qty 2



Hex Bolt 1/4"-20 UNC x 3/4" Long Qty 4



Flat Washer 1/4" Qty 8



Nylock Nut 1/4"-20 UNC Qty 4



Carriage Bolt 5/16"-18 UNC x 3/4" Long Oty 2




Flat Washer, Stainless 5/16" Qty 2



Nylock Nut, Stainless 5/16"-18 UNC Oty 2

BAG LABELED AS

MB3043-KIT03



Paddle Actuator Qty 4



Round Head Screw #10-24 x 3/4" Long Qty 34



Flat Washer M6 Qty 8




Nylock Nut #10-24 UNC Qty 8



Release Cable Qty 4




CONTENTS






ASSEMBLY - STEP 1






ASSEMBLY - STEP 2











9

MB3043 - Assembly Instructions Rear Half Doors JL/JLU/JT






ASSEMBLY - STEP 5



BAG LABELED AS MB3043-KIT03




ASSEMBLY - STEP 6





ASSEMBLY - STEP 7



BAG LABELED AS MB3043-KIT03



ASSEMBLY - STEP 8

FINAL ASSEMBLY & ADJUSTMENT

- 1. Ensure hinge bolts are loose
- 2. Place assembled half door on vehicle door hinges
- 3. Close the door & view the door from the side of the vehicle
- 4. Adjust the door to ensure there is an even reveal & gaps from left to right & top to bottom
- 5. With the door remaining closed, tighten the hinges bolts
- 6. Open the door & adjust the rotary latch fasteners as well as the rubber bumper so that the door latches smoothly & the door sits flush with the outer body

