

FUSION™

MINERAL PAINT

With exceptional adhesion, coverage and durability, your piece is bound to last for many years to come. Remember that a little prep goes a long way! So for optimum results, spend a little time assessing and prepping your piece with our simple prep guide.

HOW TO PREP LIKE A PRO:

01.

Ensure your piece is free of dirt, oil and grease.

02.

Choose your surface and follow recommended prep tips.

03.

Paint it Beautiful™!

CHOOSE YOUR SURFACE:

Melamine, Thermofoil or Laminate that are super slick. Extremely detailed high gloss carvings that can't be scuff sanded.

Roll on a very thin coat of Ultra Grip with a microfibre roller or sponge applicator.

**We recommend Microfibre roller to avoid brushstrokes or bubbles from a foam roller.*

High Gloss Paint, Lacquer or Varnish.

Scuff sand with 220 grit and remove dust.

**Wear appropriate safety equipment and respirators. Do not sand LEAD based paint.*

Old Paint or Finishes with a dull finish, Non-Rusting Metal or Glass.

Paint it Beautiful™!

Bleed through or Knots to seal.

Apply BIN Shellac Primer.

Soft Wax, Siliconized Polish or New Metal with Oil coating.

Remove with odourless solvent or mineral spirits.

FOR MORE TIPS AND INSPIRATION, VISIT:
FUSIONMINERALPAINT.COM

APPLICATION

Paint it Beautiful™ with our Fusion™ brushes & accessories.

Whether it's a hand-painted look using our natural bristle brush, or a flawless finish using our synthetic brush or microfiber roller, creativity is truly at your fingertips.

Tip: **Less is more!**

- If you see paint lines while painting, remove excess paint from your brush and smooth it out.
- Recoat after 2 hours. If Ultra Grip was applied, wait 12 hours before applying a coat of paint for best results.

Tip: **Not sure if your piece needs Ultra Grip?**

- Paint a small test patch area, if there is no lacing or beading up of the paint within 30 seconds, then simply clean and Paint it Beautiful!

Tip: **How to know if there is wax on your piece?**

- Do a finger nail scratch test, if anything comes up under your nail, most likely there is a waxy substance that needs to be removed.

Tip: **Distressing couldn't be easier with our Beeswax Block.**

- Press block along edges and areas you wish to distress between layers of different colours. Paint applied on top of the beeswax will easily come off when wet or dry sanding.

Tip: **Clean up the paint with soap and water!**

Distressing is EASY with Fusion™!

RUSTIC LOOK: Use a 220 grit sandpaper to distress and wear away to your desired look. For an aged or washed out look, try dry brushing. Dab your brush into paint, remove excess leaving your brush feeling dry, then brush over top.

NATURAL LOOK: Wet distress with a damp cloth or finishing pad 30 minutes after application.

FINISH

No additional top coat is required – Fusion™ has a built in top coat! To get a different look, effect or sheen, you can add any of our range of top coats.

- Fusion™ has a built in top coat that is very durable, stain resistant and water-resistant once cured (approximately 21 days).
- Fusion™ dries to a gorgeous soft, matte finish. For an increase sheen apply a wax, or hemp oil.
- Our Tough Coat™ Matte or Gloss Wipe-On Poly is a non-yellowing finish that provides superior durability for super high traffic areas such as kitchen cabinets or table tops. Recommended only on light to medium colours – may go cloudy over dark colours. We recommend Stain & Finishing Oil over dark colours for added sheen.

Tip: **Build your confidence, learn the basics + great techniques in a Workshop from your local Fusion Mineral Paint™ merchant or visit our YouTube Channel!**

