

Instructions for the 'CLASSIC' sectional style flagpole

TOOLS & MATERIALS NEEDED:

- POST HOLE DIGGER/SHOVEL
- LEVEL
- TAPE MEASURE
- MIXING CONTAINER
- 80lbs. + OF QUICK SETTING CEMENT
- APPROX. 3" OF GRAVEL

FLAGPOLE KIT INCLUDES:

- ALUMINUM GROUND SLEEVE
 - ALUMINUM GOLD BALL
 - 3 TO 5 ALUMINUM FLAGPOLE SECTIONS
(DEPENDING ON SIZE—13'³/₈, 17'¹/₄, 21'¹/₅)
 - TRUCK TOP, PRE-ASSEMBLED TO POLE
 - CLEAT, PRE-ASSEMBLED TO POLE
 - ROPE, PRE-STRUNG
 - 3' x 5' NYLON SEWN USA FLAG
 - CLIP PACK (4 NYLON CLIPS) WITH FLAG ETIQUETTE LEAFLET
 - MANUFACTURER PRODUCT WARRANTY REGISTRATION
- (MUST BE RETURNED WITHIN 90 DAYS OF PURCHASE OR WARRANTY IS VOID)**



STEP 1. SELECT FLAGPOLE LOCATION. **CALL 811 BEFORE YOU DIG.** CHECK FOR UNDERGROUND SPRINKLERS, WATER LINES AND ELECTRICAL LINES (MAKE SURE YOUR FLAG HAS CLEARANCE TO FLY IN ALL DIRECTIONS)

STEP 2. DIG A HOLE APPROX. 26" DEEP BY 12" IN DIAMETER (26"L x 12"W)

STEP 3. PLACE APPROX. 3" OF GRAVEL IN HOLE (ALLOWS FOR DRAINAGE)

STEP 4. PLACE ALUMINUM GROUND SLEEVE **BEAD DOWN** INTO GRAVEL— TO PREVENT CONCRETE FROM FLOWING INSIDE

STEP 5. MIX CEMENT AND POUR AROUND GROUND SLEEVE. REPEAT UNTIL HOLE IS FILLED (IT'S OK TO HAVE YOUR GROUND SLEEVE AN INCH OR TWO ABOVE GROUND LEVEL—FILLING IN WITH MULCH, DIRT, FLOWER BED)

STEP 6. INSERT POLE SECTION INTO GROUND SLEEVE (CAREFULLY — CEMENT WILL BE WET) **SWEDGE END UP**, USE A LEVEL TO MAKE SURE POLE IS STRAIGHT

REMOVE POLE SECTION AFTER LEVEL, CONCRETE MUST CURE FOR AT LEAST 24 HOURS

STEP 7. ASSEMBLE FLAGPOLE, ATTACH BALL, CLIPS, AND FLAG

STEP 8. INSERT INTO GROUND SLEEVE. ENJOY OLD GLORY!

FOR PARTS AND SERVICE:

EZPOLE FLAGPOLES/ 1489 EAST 363RD STREET/ EASTLAKE, OHIO 44095

TOLL FREE: 888-454-9164/ LOCAL: 440-951-1011/ FAX: 440-951-2933/ www.ezpole.com

