
## Oxygen and acetylene gauges used on Reel Rig™ mounting hardware

Instructions and order of installation.



Step 2: Assemble oxygen gauge and parts as shown. Use teflon on threads with no seating end. Read all instructions before you start. do not overtighten.



Step 3: Assemble acetelene gauge and parts as shown. Use teflon on threads with no seating end. Read all instructions before you start. Do not overtighten.

