

Furniture Fitting Guide

1. Please examine your purchased items carefully, in the case of any of the items having a defect, please do NOT install as returns will not be accepted once fitted.
2. It is advised that you use a qualified fitter to install your units, as any issues relating to ill fitted units will not be accepted by the Supplier.
3. This Product is Water Resistant but not Water Proof. On no account should spillages/ splashes, of even water be allowed to lie on any surface. Any such spillage/ splashes should be wiped dry, failure to do so may shorten the life expectancy of the product and invalidate any guarantees.
4. Please avoid direct sunlight as this will cause any painted surfaces to discolor.
5. Due to motion in transit, the cabinet doors/ drawers may need to be adjusted after installation.
6. Floor Standing Units must be fitted directly to the wall through the back rail using suitable fixings (not supplied)
7. The basin should also be secured where applicable using Fischer Bolts through the fixing points under the basin (not supplied).
8. Wall Hung Units should be secured directly to the wall using the wall hanging bracket (supplied) or suitable wall fixings when no supplied. Additional support is recommended using “L” brackets (not supplied).
9. When fixing to a stud or paneled wall, appropriate frame work should be installed or support the basins and units.
10. Where Units/ Worktops must be cut-out for services, all raw edges MUST be sealed against water ingress.

BATH PANEL FITTING INSTRUCTION



1. Measure from the Underside of the Bath Rim to the Floor to Establish the Height of the Bath Panel Required.
2. Drill equally spaced holes along the plinth and screw to the bottom edge of the main panel at the desired height.
3. It is advisable that you build a frame or fit battens along the floor and down the wall sides to support the panel.
4. When an end panel is used, it is necessary to trim the panel and plinth to length. Any trimming should be done at the wall end to ensure that the finished edge is at the visible corner. The front and end panels are fastened together using the screws and corner brackets provided.
5. Any cut or trimmed edges **MUST** be sealed against water ingress. It is also advisable to seal all the outer edges of the panels and the underside of the bath lip where the panel meets.