

Recommended Installation for Pedestal with Basin.

1. Place the basin in position ensuring this is level and the bottom of the bowl is at the correct height so that when using a pedestal the two pieces will meet.
2. Mark the fixings holes and remove the basin, using suitable wall fixings (not supplied) if the basin to the wall ensuring that it is level.
3. Place the pedestal under the basin and mark the screw hole positions in the floor, using suitable screws fix the pedestal down to the floor.
4. Run a bead of clear silicone between the basin and the pedestal to finish and leave for 24 hours before use.

