

REMOVING SUPPORTS FROM COCKPIT NOSECONE AND CLEAR INSERT FOR DEAGOSTINI MILLENNIUM FALCON

1. Lets remove the base and supports from the clear insert first



3. ... or an X-Acto knife



5. The supprts can be removed by hand...



2. Start by cutting off the supports from the base with a pair of sidecutters...



4. In the end you should have your base separated as shown



6. ... or with the use of an X-Acto knife





7. This is the final result





Continue on Page 2

3. Continue by removing the rest of the thinner supports

2. Start by snipping off the base supports

Page 2

4. Carefully remove the window frame supports on the sides by using a pair of sharp sidecutters

cut off

6. ... until all of the supports have been

7. You should be able to the support

separate your nosecone from the base and structure now

10. All done!

8. Cut off the

the base with a sharp knife

door frame from







Ĭ

Inninia







