





CONFIRM PARTS:
(3) Panel Blind Flip Tops
(3) Support Bars
(4) Extension Bars
(2) Extension Bars labeled (A)



2. ATTACH SUPPORT BARS From the inside of the panel blind, attach support bars where the black connection pieces fit through the cut-outs.



**3. ATTACH EXTENSION BARS** Make sure you line up the A bar with the A Flip Top (this is your middle panel flip top).



**4. ATTACH FLIP TOPS** Using the pins from the support bars, secure the flip top into position.