

MFC Offroad PDCV1 Wiring Diagram

Pictured below is the wiring schematics for a simple installation. The design of the custom mount allows you to use already placed bolts that mount the ecu to the battery tray. Please note, some battery trays differ by year so there may need to be minor trimming for a flush installation. This trimming is usually done by trimming back 1/4" of plastic that sits at the highest part of the tray. By loosening the nuts and sliding the mount into the space with the prongs of the mount beside the bolts, you just tighten down the nuts again to compress the PDCV1 to hold it in place. You will have over an inch of space above the battery when installed correctly. Please refer to the more detailed installation instructions for further installation notes.

