

GREGSRACEPARTS.COM

Hydraulic Trunk Lid Strut Kit Installation Guide

Kit inventory

Kit inventory		
Item	Quantity	
Gas Charged Strut	1	
Valve cover mount bracket (square s	shaped) 1	
Trunk lid bracket (triangular shaped) 1	
6mm trunk lid bracket nuts	2	
5/16" strut mount nuts	2	
5/16" strut mount washers	2	



Step one	Layout parts and ensure all items are included with the kit.	
Step two	Assemble gas strut with brackets. Larger portion of the strut goes toward the valve cover. Place washer onto swivel head threads of strut. Slide thread through the inside of the bracket Fix to bracket by holding the bracket thread with a 13mm wrench while tightening the supplied nut. Repeat for trunk lid bracket. The thread must pass through the inside of the bracket.	
Step three	Open the trunk lid and support with the factory prop.	
Step four	Install the valve cover bracket. O Use the factory OEM 10mm head bolt. Take care to not over tighten.	
Step five	 Install the trunk lid bracket. Remove the two factory OEM nuts from the studs in the trunk lid near the latch assembly and discard. Raise the trunk lid carefully and slide the studs through the matching holes on the bracket. Slide the supplied nuts onto the factory studs by hand, and tighten evenly with a socket. Take care not to over tighten nuts, or raise the trunk lid too high and contact the car body. 	
Step six	Check and test operation. Check fasteners are tight. Test trunk lid should operate freely without binding. The trunk will require a slight lift to assist the strut to open fully.	

Enjoy the convenience of your new GRP Strut Kit! Feel free to call or email with any installation questions.

Email: gregsraceparts@gmail.com

Phone: 833.477.2787

Web: www.gregsraceparts.com



GREGSRACEPARTS.COM











