



1. For black piano finish, remove the insert protective film. Film may be removed near hub due to factory assembly – this is normal.
2. Remove all items from console before install.
3. Position insert above console
4. Guide the insert into console.
5. Plug the USB cable in.
6. **Take precaution** if too much force is applied the console felt can be scuffed and damaged.
7. For storage bin variant with felt mats remove the adhesive protective film on 1 side, center mat in the bin and lay flat.
8. For storage bin variant with premium sticky pad remove the protective film on both sides, center the pad in the bin and lay flat. The sticky pad can be removed and rinsed with water to clean dust particle over time..

questions?
shoot us an email at
info@helloskyline.com

please leave product reviews
on our site and Amazon!