




- ① slide original dock trim cover to the left to remove



- ② insert charging cables through SKYLINE adapter



- ③ press cables into the slots on the SKYLINE adapter, and slide the adapter into place on the console



- ④ slide original trim cover onto SKYLINE adapter