

7300 SUREBOND

Urethane Wood Flooring Adhesive

OWNED & OPERATED
IN USA



TECHNICAL DATA SHEET

DriTac 7300 is a contractor grade, urethane wood flooring adhesive that is very easy to spread and dispense from the pail, allowing for increased productivity. It contains no water and provides a permanent bond.

FLOORING TYPES

- Parquet
- Bamboo
- Plywood
- Exotic Woods
- Multi-Ply Engineered Plank
- Solid Wood Planks
- Acrylic Impregnated Wood
- Recycled Rubber Flooring

ATTRIBUTES

- Easy to Spread
- High Solids
- Non-Slumping
- Low Odor
- Freeze-Thaw Stable
- Remains Elastomeric
- Easy to Clean When Wet
- Helps Contribute to LEED Credits

Available Container Size: 2-Gallon and 4-Gallon Pail



DriTac
Adhering to Excellence

TECHNICAL DATA SHEET

INSTRUCTIONS

Read all information before installation. Please contact DriTac Flooring Products at (973) 614-9000 with questions.

GENERAL CHARACTERISTICS

DriTac 7300 has been formulated for the interior installation of multi-ply engineered plank, solid plank, bamboo, exotic wood, acrylic impregnated wood, parquet, plywood, recycled rubber flooring and cork and rubber underlayments over approved substrates. DriTac 7300 is moisture resistant, however, to prevent damage to the flooring from subfloor moisture, carefully follow the wood manufacturer's instructions. The time it takes for the adhesive to cure is related to temperature, humidity, porosity of the subfloor, ventilation and air movement.

APPROVED SUBFLOORS

- Plywood
- Terrazzo and ceramic tile
- Underlayment grade O.S.B.
- Vinyl tile flooring coated with vinyl primer
- Concrete; above, on or below grade in the absence of excessive moisture and alkalinity
- Non-cushioned fully adhered sheet vinyl coated with vinyl primer
- Lightweight concrete/gypcrete (coated with latex primer), per ASTM F2419

Note: If DriTac's list of approved subfloors is different from the flooring manufacturer, DriTac requires that you must follow the flooring manufacturer's recommendation.

SUBFLOOR REQUIREMENTS

- Clean - It is required that all concrete, sheet vinyl, vinyl tile, terrazzo and ceramic tile subfloors be scoured with #3-1/2 open coat sandpaper to remove dirt or any surface contamination such as paint, grease, oil, sealers, waxes and curing compounds. DriTac 7300 adhesive should not be used over these substances. Sweep or vacuum the subfloor before installation.
- Preparation - All floors should be flat to within 3/16" in 10 ft. or 1/8" in 6 ft.
- Smooth and Flat - Remove any high spots with a terrazzo grinder or Carborundum stone and fill any low spots with a good quality cementitious-based latex patch mix.

CONCRETE SUBFLOORS

Concrete should be at least 60 days old. Inspect the concrete before installing flooring over it. First inspect for any wetness at the base of the drywall or for visible signs of moisture on the concrete. Second, test for moisture. Use a Calcium Chloride Method Test or Relative Humidity Test for reliable concrete testing. The results should not exceed 3 lbs., per 1,000 square feet over 24 hours, per the ASTM F1869 Calcium Chloride Method Test, or 75% Relative Humidity (RH), per the ASTM F2170 Relative Humidity Method Test. The maximum reading on concrete for wood installations should not exceed the wood flooring manufacturer's recommendations. Many wood flooring products can be installed over lightweight concrete (less than 3000 PSI) or gypcrete, providing the surface is properly prepared. Follow the concrete manufacturer's recommendation for the application of a surface hardener/sealer. Radiant heated subfloors should be turned off 24 hours prior to and during installation to prevent premature curing of the adhesive.

SHEET VINYL, VINYL TILE, TERRAZZO & CERAMIC TILE SUBFLOORS

All tiles or sheet goods must be firmly bonded to the subfloor. Make certain the sheet vinyl is a full spread system, perimeter installations are unacceptable. If materials are poorly bonded to the subfloor remove them down to the original subfloor and sand or scrape off all traces of old adhesive. Do not glue over heavy cushioned (1/4") sheet goods or rubber tile. New sheet vinyl or vinyl tile must be coated with a primer. Old vinyl must be sanded first, then cleaned with TSP or equivalent cleaner to remove all wax and other coatings.

CAUTION: Sanding or removing tile flooring containing asbestos is a health hazard. If there is any doubt concerning the contents, professional advice should be sought. Asbestos has been labeled a carcinogen.

PLYWOOD, ORIENTED STRAND BOARD (OSB), OR WOOD SUBFLOORS

CAUTION: Subfloors with high moisture content may shrink at a later date causing cracks to appear in the wood floor.

Before installing over any one of these subfloors, test for moisture using a reliable moisture meter such as the Tramex Wood Moisture Meter or equivalent. The moisture content should not exceed 12%. If it is over 12%, either wait until the subfloor is drier or stabilize the subfloor with an additional layer of 1/4" plywood. All joints in subflooring materials should have 1/8" expansion space around all panels. If expansion space is not present, cut around and through the panel joints with a circular saw. When installing a plywood sheet subfloor over concrete, use a 1/4" x 1/4" x 1/4" square notched trowel to apply adhesive. Score 3/8" deep every 8 to 10 inches on 4' x 4' sheets of 3/4" exterior. Set 4' x 4' sheets into wet adhesive. Apply weight as necessary and allow to cure overnight.

WOOD INSTALLATIONS

DriTac 7300 flows from the pail very easily. For best results, tip the pail carefully to dispense adhesive. Provide adequate ventilation and air movement. Ideally, installation should not begin until all wet work (painting, dry wall materials, etc.) is complete and the

TECHNICAL DATA SHEET

heating/air conditioning system is in operation. Jobsite temperature should be between 55 and 90 degrees Fahrenheit. Trowel only the amount of adhesive that can be covered in 30 minutes. Install wood flooring into wet adhesive only. Secure the first row with edge blocking or top nail with finishing or sprig nails. Tighten side and end joints and reduce scooting by securing the flooring together with a manufacturer-approved method (painters tape, side blocking, strapping, etc.). Occasionally check for transfer to back of wood flooring. If adhesive transfer is less than 90% to the back of the plank scrape up the adhesive and apply fresh DriTac 7300. Apply weight to any bowed flooring and all floor mounted trim moldings. Remove all defective or unsightly boards immediately. The adhesive is very tenacious and flooring is difficult to remove after the adhesive has cured. Roll the floor with a 100 lb. roller every two to three hours during and immediately after installation.

RECYCLED RUBBER FLOORING INSTALLATIONS








This product is approved for installing all recycled rubber flooring products that are recommended for installation with a moisture cure urethane adhesive. Check with the flooring manufacturer for installation recommendations.

APPROVED CORK & RUBBER UNDERLAYMENT INSTALLATIONS

- Cut underlayment to length and lay loosely over the area to be installed. Both ends of the roll must curl down towards the subfloor. If the ends curl up, turn the underlayment over.
- Pull the loose laid material back at least half the length of the roll. Using the recommended trowel, apply DriTac 7300 to the subfloor. Place underlayment into adhesive utilizing wet-lay method. Upon placing underlayment into the adhesive, roll both ways with a 100 lb roller. Repeat the installation for the other half of the subfloor, insuring all joints are butted together tightly.
- Allow adhesive to set prior to proceeding to flooring installation. It is highly recommended to allow at least 18 hours prior to installation of the flooring.

GLUE/NAIL ASSIST INSTALLATIONS

This adhesive can be used for glue and nail assist installations, when recommended in writing by the wood flooring manufacturer. DriTac 7300 adhesive sausages are available for glue assist installations.

TROWELS AND COVERAGE		
Floor Type	DriTac Trowel	Coverage
Multi-ply Engineered Plank 3/8" up to 1/2"	 TR-2 3/16" x 1/4" x 5/16" Flat V Notch	60 sq. feet/gal.
Multi-Ply Engineered Plank 3/8" up to 1/2" and 5/16" to 3/8" solid strip	 TR-6 3/16" x 3/16" x 5/32" V Notch	50 sq. feet/gal.
5/16" Solid Parquet, 1/4" Engineered Plank	 TR-5 1/8" x 1/8" x 1/8" Square Notch	80 sq. feet/gal.
3/4" Solid Wood Plank/ Shorts, 4' x 4' Plywood	 TR-4 1/4" x 1/4" x 1/4" Square Notch	30 sq. feet/gal.
Greater than 1/2" Engineered Plank, 3/4" Parquet and Solid Plank greater than 3/8" up to 9/16"	 TR-7 1/4" x 1/4" x 1/8" Square Notch	35 sq. feet/gal.
Bamboo up to 5/8" in thickness	 TR-9 3/16" x 3/16" x 3/16" Square Notch	35 sq. feet/gal.
Recycled Rubber Flooring over Non-Porous Substrates	 TR-15 3/32" x 3/32" x 3/32" Square Notch	100 sq. feet/gal.

Trowels diagrams are not to scale. Use DriTac 7300 adhesive with a properly notched trowel. All square footage rates are estimated. Rates will vary based on substrate condition and the angle the trowel is held to the subfloor. Failure to properly flatten the subfloor may result in hollow spots. DriTac warranties do not cover problems caused by improper use of installation products. Follow flooring manufacturer's written installations instructions.

TECHNICAL DATA SHEET

LIMITATIONS

Adhesive will not prevent moisture-related damage to wood flooring installations. DriTac 7300 adhesive is affected by humidity more than temperature. High humidity will cause the adhesive to cure faster and low humidity will slow the curing process. Do not use on wet, contaminated or friable substrates. Due to dimensional stability, only engineered plank wood flooring can be installed below-grade, when proper moisture testing has been conducted and the results do not exceed limitations. After 8 to 12 hours, light traffic is allowed. Do not use as a leveling material. Cutback residue must be removed or encapsulated prior to applying adhesive.

REUSE OF PARTIAL CONTAINERS

Cover adhesive in the pail with a plastic trash bag or two layers of plastic film. Put lid on tightly. Turn over pail. This will seal contents from outside air. To open container, take off lid, cut plastic and remove thin layer of cured adhesive on surface.

SHELF LIFE

12 months when stored at 75° F and 50% relative humidity.

CLEAN UP

- Remove excess urethane adhesive as soon as possible before it dries on the flooring surface. Clean up as you go. Cured urethane adhesive is very difficult to remove.
- Never attempt to remove DriTac 7300 adhesive from tools or flooring with water as this will cause the adhesive to cure more rapidly.
- Remove residue before it dries with DriTac Urethane Adhesive Remover or other flooring manufacturer-approved cleaning method.
- Clean DriTac 7300 adhesive from floor and tools while still wet with DriTac Urethane Adhesive Remover or other flooring manufacturer-approved cleaning method.

PRECAUTIONS

- Contains Methylene Diphenyl Diisocyanate. May cause skin and/or eye irritation. May cause dermatitis and allergic responses. Potential skin and/or respiratory sensitizer. Inhalation of vapors may cause irritation and intoxication with headaches, dizziness, and nausea. See Safety Data Sheets for further information. Ingestion may cause irritation.
 - KEEP OUT OF REACH OF CHILDREN. Avoid contact with skin, eyes and clothing. Wash thoroughly after handling. Avoid breathing vapors. Use only with adequate ventilation. Use impervious gloves, eye protection and if TLV is exceeded or if used in a poorly ventilated area, use NIOSH/MSMA approved respiratory protection in accordance with applicable federal, state and local regulations. DO NOT take internally.
- Empty container may contain hazardous residues.

FIRST AID


In case of eye contact, flush thoroughly with water for at least 15 minutes. SEEK IMMEDIATE MEDICAL ATTENTION. In case of skin contact, wash affected areas with soap and water. If irritation persists, SEEK MEDICAL ATTENTION. Remove and wash all contaminated clothing. If inhalation causes physical discomfort, remove to fresh air. If discomfort persists, SEEK MEDICAL ATTENTION.

INSTALLER RESPONSIBILITY

These directions are general guidelines for flooring installations. It is the responsibility of the installer to determine proper drying time of the adhesive, trowel size to be used and acceptability of subfloor conditions. Installations must also be in accordance with flooring manufacturers recommendations. Only flooring that is approved for glue down installations by the flooring manufacturer can be used with DriTac 7300. Floors installed with DriTac 7300 are not warranted against damage caused by wet mopping, flooding, plumbing leaks or other extraordinary circumstances. For any installation not herein recommended, contact DriTac Flooring Products before proceeding.

WARRANTY

This product is warranted to be free of manufacturing defects. If a manufacturing defect is found within one year from the date of purchase, such defective product shall be replaced. No warranty either expressed or implied is made regarding the performance of this product since conditions under which these goods are transported, stored, used or applied are beyond our control. This warranty is made in lieu of all other warranties either expressed or implied and the seller shall not be responsible for consequential, incidental, special or other damages no matter what the cause.

GHS label elements: Hazard pictograms:  Signal word: Warning. Hazard statements: Causes skin irritation. Causes serious eye irritation. May cause an allergic skin reaction. May cause respiratory irritation. Precautionary statements: Wear protective gloves: butyl rubber, Ethyl vinyl alcohol laminate (EVAL), nitrile rubber, neoprene rubber. Wear eye and face protection. Wear protective clothing. Avoid breathing vapor. Avoid release to the environment. Wash hands thoroughly after handling. Collect spillage.