#### BUMPER PLACEMENT INSTRUCTIONS

# TO PLA TOP

#### FOR iPAD 2 & NEWER ONLY



TO CONVERT CRADLE FOR THE IPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



## **BUMPER PLACEMENT INSTRUCTIONS**

FOR iPAD 2 & NEWER ONLY





TO CONVERT CRADLE FOR THE IPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



# BUMPER PLACEMENT INSTRUCTIONS

FOR iPAD 2 & NEWER ONLY





TO CONVERT CRADLE FOR THE IPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



#### BUMPER PLACEMENT INSTRUCTIONS





TO CONVERT CRADLE FOR THE iPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



#### **BUMPER PLACEMENT INSTRUCTIONS**

# FOR iPAD 2 & NEWER ONLY





TO CONVERT CRADLE FOR THE IPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



## **BUMPER PLACEMENT INSTRUCTIONS**

FOR iPAD 2 & NEWER ONLY





TO CONVERT CRADLE FOR THE iPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



# **BUMPER PLACEMENT INSTRUCTIONS**

FOR iPAD 2 & NEWER ONLY





TO CONVERT CRADLE FOR THE IPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



#### **BUMPER PLACEMENT INSTRUCTIONS**

FOR iPAD 2 & NEWER ONLY





TO CONVERT CRADLE FOR THE IPAD 2, PLACE BLACK ADHESIVE BUMPERS TO TOP CORNERS OF CRADLE AS SHOWN.



RMR-INS-AP8