

1" BALL ADAPTER CHARGING INSTRUCTIONS



more info

pkdsn.com/chargingballadapter

GET TO KNOW YOUR MOUNT

requires Peak Design Case or MagSafe Phone/Case not included



Embedded Magnets x4

USB-C



Cable Clips x3



Charging Port



USB-C to USB-C Cable (1m)

INSTALLATION



Connect Peak Design 1" **Ball Adapter** to 3rd party 1" ball and socket mount. Tighten to 3rd-party specifications.

Allow alcohol to dry when using included wipe to clean surfaces for **Cable Clips**.



Stay safe. Do not interact with or remove your phone from the mount while in motion.

ATTACH/DETACH PHONE



The **Mount Head** magnetically connects to the back of your phone. Once connected, confirm phone is charging via phone screen.

WARNING: If not attached correctly, product and/or phone may dislodge or be thrown into air in event of crash. Consult your car's manual to ensure mount does not cover or interfere with operation of airbag.