## 1" BALL ADAPTER LOCKING INSTRUCTIONS



more info
pkdsn.com/balladapter



## **INSTALLATION**



Connect Peak Design 1" Ball Adapter to 3rd party 1" ball and socket mount. Tighten to 3rd-party specifications.



## ATTACH/DETACH PHONE



To attach, place phone on mount and listen for "click" to ensure phone is locked. Requires **Peak Design Case** (sold separately)

To detach, push EITHER of the **Release Buttons** and pull phone outward.



