

Assembly Instructions for Ball Head with 4-Point Adapter

1. Loosen the set screw on the gooseneck
2. Insert the 3/8" screw into flanged sleeve, thread into gooseneck, gently tighten set screw
3. Assemble clamshell around head of 3/8" screw and 4-point adapter ball as shown

TOOLS REQUIRED: 2 mm Allen wrench (included with gooseneck)



SnakeClamp Products LLC

www.SnakeClamp.com support@snakeclamp.com

snakeclamp