

## Assembly Instructions for Large Mirror

Loosen the set screw at the end of the gooseneck. Attach the Large Mirror to the gooseneck arm using the 3/8" screw. Insert lock washer as shown. Gently tighten the set screw.

TOOLS REQUIRED: 7/32 and 2 mm Allen wrench (included)



SnakeClamp Products LLC

[www.SnakeClamp.com](http://www.SnakeClamp.com)

[support@snakeclamp.com](mailto:support@snakeclamp.com)

The logo for SnakeClamp, featuring a stylized red snake head above the brand name "snakeclamp" in a bold, lowercase font.