

## How To Assemble Your Rail Clamp

Loosen the set screw at the end of the gooseneck arm. Then attach the gooseneck arm to the rail clamp using one 3/8" flat-head screw. Insert lock washer and washer as shown. Then GENTLY tighten the set screw.

TOOLS REQUIRED: 2 mm and 7/32" Allen wrench (included)



- SnakeClamp Products -

[www.SnakeClamp.com](http://www.SnakeClamp.com)

[support@snakeclamp.com](mailto:support@snakeclamp.com)

**snakeclamp**