

How To Assemble Your Smartphone Mount

Place the Smartphone Mount onto the 4-point adapter and slide until it snaps into the locked position. You will feel it "click."

NOTE: 7/32" and 2mm Allen wrenches are included for assembly/disassembly. Keep these in a safe place.

TOOLS REQUIRED: 2 mm and 7/32" Allen wrench (included)



The 4-point adapter may be pre-assembled to the gooseneck arm.

May Be Pre-Assembled:



IMPORTANT: If you wish to disassemble your SnakeClamp, loosen the set screw using the included 2mm Allen Wrench **PRIOR** to removing the 3/8" screw.

When reassembling your SnakeClamp, tighten the 3/8" screw so that the spring washer is slightly compressed. Then gently tighten the set screw.

SnakeClamp Products LLC

www.SnakeClamp.com support@snakeclamp.com

 snakeclamp