

Assembly Instructions for Suction Cup Mount

Loosen the set screw at the end of the flexible gooseneck arm. The set screw may be included in your parts bag. Insert the 3/8" screw, AMPS Adapter, flat washer and lock washer in the order shown. Tighten the 3/8" screw using the large Allen wrench. Then gently tighten the set screw using the small Allen wrench. Lastly, attach the AMPS Adapter to the suction cup with the black screws included with the suction cup.

NOTE: 7/32" and 2mm Allen wrenches are included for assembly/disassembly. Keep these in a safe place.

TOOLS REQUIRED: 2mm and 7/32 Allen wrenches (included), Phillips head screwdriver



SnakeClamp Products LLC

www.SnakeClamp.com

support@snakeclamp.com

snakeclamp